

LogiLink®



Door & Window Mini Alarm

Art. No.: SC0207

A simple and effective way to build your home security system.

Features:

- » Magnetic trigger technology
- » Alarm siren sounds at 115dB
- » Compact design fits on all doors and windows
- » Perfect for Home, Office, Dorm Room or Even RVs
- » Easy installation, no tools needed
- » Prevent young children or wandering elderly from leaving the house
- » Key to arm/disarm unit
- » Includes LR44 Cell batteries



Battery Installation:

Remove the cover of the battery compartment and insert three AG13 (LR44) (each 1.5 V/CD) button cells into the battery case according to the correct polarity.



Installation:

- (1) Put the included double-sided adhesive tape on the back side of the main unit and the magnetic contact.
- (2) Mount the main unit on the door or window frame and the magnetic contact on the door or window. Make sure the gap between them is less than 1.27cm.
- (3) Pull out the disarm key to activate the alarm.
- (4) When the magnetic contact is separated from the main unit, the alarm will sound.
- (5) Insert the disarm key in the alarm to turn it off.



SC0207



Made in China



* The specifications and pictures are subject to change without notice.
*All trade names referenced are the registered namework of their respective owners.

LogiLink®



Door & Window Mini Alarm

Art. No.: SC0207



Package Contents:

- » 1 x Door & Window Mini Alarm
- » 2 x Adhesive tape
- » 3 x LR44 Cell batteries

Package Informations:

- » Packing Dimension: 180mm x 100mm x 25mm
- » Packing Weight: 0,055kg
- » Carton Dimension: 480 x 410 x 240mm
- » Carton Q'ty: 100pcs
- » Carton Weight: 6,7kg

Warning:

At close range the siren may cause ear damage.



SC0207



Made in China



RoHS
compliant



* The specifications and pictures are subject to change without notice.
* All trade names referenced are the registered namework of their respective owners.