LogiLink_®



Panic Alarm

Art. No.: SC0210

This Panic Alarm features fast and simple squeeze and scare operation that allows you to activate the alarm quickly at the same time you grab the unit at 120dB alerting anyone up to 70m away!

This compact alarm with clip-on attachment & built-in keychain hole lets you easily attach your keys or clip to your purse or clothing so it is always within reach.

It also has a built-in bright white LED flashlight, which can be used to illuminate darkened doorways, car key slots, or to help you find your way in a power outage. The flashlight can be used only when the alarm is unarmed.

Features:

- » Clip-on attachment & built-in keychain hole
- » Built-in LED light function
- » Fast activation by squeezing the unit on both sides
- » Alarm siren sounds at 120dB
- » Suitable for joggers, women, children, the elderly, the disabled, night shift workers, and people who are alone
- » Constructed of durable ABS plastic
- » Dimension: 75mm x 40mm x 12mm
- » Included 3 x LR44 (AG13) button cells



Using as a personal alarm:

- 1) Simply squeeze the unit on both sides to trigger the personal alarm.
- 2) The 120dB alarm will sound.
- 3) To stop the alarm, press the light switch button on the front cover.









LogiLink_®



Panic Alarm

Art. No.: SC0210

Flashlight Usage:

Press on the light switch button on the front cover of the unit to use flashlight.



Changing Battery:

Unscrew the 4 screws on the back to change the batteries.

*Please remove the plastic tab to use the product for the first time.











Package Contents:

- » 1 x Panic Alarm
- » 3 x LR44 (AG13) button cell batteries

Package Informations:

» Packing Dimension: 135mm x 135mm x 30mm

» Packing Weight: 0,05kg

» Carton Dimension: 480 x 410 x 240mm

» Carton Q'ty: 100pcs » Carton Weight: 5,2kg

Warning:

At close range the siren may cause ear damage. Keep away from children and pets.









